


Responsibility is not accepted for errors made by others in scaling from this drawing. All construction information should be taken from figured dimensions only.							



Substation and Plant Store	,
SUITABILITY STATUS	SCALE
PL : Authorized and accepted	1:50@A2
DRAWING USAGE:	

DRAWING USAGE:	
PROJECT - ORIGINATOR - VOLUME - LEVEL - TYPE - ROLE - CLASS NUMBER	STATUS_REVISION
SNPS-STL-XX-XX-DR-L-9402	PL_PL04